



User manual

UM EN ILC 1XX

Installing and operating the ILC 130 ETH,
ILC 150 ETH, ILC 155 ETH, ILC 170 ETH 2TX,
and ILC 190 ETH 2TX Inline controllers

User manual

Installing and operating the ILC 130 ETH, ILC 150 ETH, ILC 155 ETH, ILC 170 ETH 2TX, and ILC 190 ETH 2TX Inline controllers

2012-01-26

Designation: UM EN ILC 1XX

Revision: 06

Order No.: —

This user manual is valid for:

Designation	Revision (HW) or later	Version (FW) or later	Order No.
ILC 130 ETH	01	3.01	2988803
ILC 150 ETH	00	2.00	2985330
ILC 155 ETH	01	2.04	2988188
ILC 170 ETH 2TX	01	3.00	2916532
ILC 190 ETH 2TX	00	3.70	2700527

Please observe the following notes

User group of this manual

The use of products described in this manual is oriented exclusively to qualified electricians or persons instructed by them, who are familiar with applicable standards and other regulations regarding electrical engineering and, in particular, the relevant safety concepts.

Explanation of symbols used and signal words



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety measures that follow this symbol to avoid possible injury or death.

There are three different categories of personal injury that are indicated with a signal word.

DANGER This indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING This indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION This indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



This symbol together with the signal word **NOTE** and the accompanying text alert the reader to a situation which may cause damage or malfunction to the device, hardware/software, or surrounding property.



This symbol and the accompanying text provide the reader with additional information or refer to detailed sources of information.

How to contact us

Internet

Up-to-date information on Phoenix Contact products and our Terms and Conditions can be found on the Internet at:

www.phoenixcontact.com

Make sure you always use the latest documentation.

It can be downloaded at:

www.phoenixcontact.net/catalog

Subsidiaries

If there are any problems that cannot be solved using the documentation, please contact your Phoenix Contact subsidiary.

Subsidiary contact information is available at www.phoenixcontact.com.

Published by

PHOENIX CONTACT GmbH & Co. KG
Flachsmarktstraße 8
32825 Blomberg
GERMANY

Should you have any suggestions or recommendations for improvement of the contents and layout of our manuals, please send your comments to:

tecdoc@phoenixcontact.com

Please observe the following notes

General terms and conditions of use for technical documentation

Phoenix Contact reserves the right to alter, correct, and/or improve the technical documentation and the products described in the technical documentation at its own discretion and without giving prior notice, insofar as this is reasonable for the user. The same applies to any technical changes that serve the purpose of technical progress.

The receipt of technical documentation (in particular user documentation) does not constitute any further duty on the part of Phoenix Contact to furnish information on modifications to products and/or technical documentation. You are responsible to verify the suitability and intended use of the products in your specific application, in particular with regard to observing the applicable standards and regulations. All information made available in the technical data is supplied without any accompanying guarantee, whether expressly mentioned, implied or tacitly assumed.

In general, the provisions of the current standard Terms and Conditions of Phoenix Contact apply exclusively, in particular as concerns any warranty liability.

This manual, including all illustrations contained herein, is copyright protected. Any changes to the contents or the publication of extracts of this document is prohibited.

Phoenix Contact reserves the right to register its own intellectual property rights for the product identifications of Phoenix Contact products that are used here. Registration of such intellectual property rights by third parties is prohibited.

Other product identifications may be afforded legal protection, even where they may not be indicated as such.

Table of contents

1	Introduction.....	1-1
1.1	Purpose of this manual.....	1-1
1.2	Hardware and software requirements	1-1
2	Description of the Inline controller.....	2-1
2.1	General description of the Inline controller.....	2-1
2.2	Possible fields of application of the Inline controller.....	2-3
2.2.1	ILC 130 ETH	2-3
2.2.2	ILC 150 ETH, ILC 155 ETH, ILC 170 ETH 2TX, and ILC 190 ETH 2TX	2-3
2.2.3	ILC 170 ETH 2TX and ILC 190 ETH 2TX as a PROFINET IO device in a PROFINET network	2-5
2.2.4	Applicative system redundancy with ILC 170 ETH 2TX or ILC 190 ETH 2TX	2-6
2.3	Notes on using the Inline controller (ILC 150 ETH/ILC 155 ETH) in potentially explosive areas	2-7
2.4	Unpacking the Inline controller	2-8
2.5	Connection and operating elements.....	2-9
2.6	Diagnostic and status indicators.....	2-11
2.7	Mode selector switch.....	2-14
2.8	Reset button (concealed)	2-15
2.9	Parameterization memory.....	2-15
2.10	Internal basic circuit diagram	2-17
2.11	Mounting and removing the Inline controller	2-18
2.12	Communication paths.....	2-21
2.12.1	Ethernet	2-22
2.12.2	Serial PRG interface (mini-DIN female connector)	2-23
2.12.3	Serial PRG interface - function blocks	2-24
2.13	INTERBUS	2-25
2.13.1	Local bus	2-25
2.13.2	Remote bus	2-25
2.14	Power supply	2-26
2.14.1	Sizing of the power supply	2-26
2.14.2	Power supply connection	2-27
2.14.3	24 V segment supply/24 V main supply	2-29
2.14.4	24 V segment supply	2-29
2.14.5	24 V main voltage	2-29
2.14.6	24 V ILC supply	2-29
2.14.7	Jumpers	2-29
2.15	Digital inputs and outputs	2-30

3	The Inline controller under PC Worx/PC Worx Express	3-1
3.1	Software version.....	3-1
3.2	Assigning the IP address for the controller/ BootP server.....	3-2
3.3	ILC 170 ETH 2TX (ILC 190 ETH 2TX) as a PROFINET IO device	3-5
3.4	Setting the realtime clock under PC Worx Express.....	3-11
3.5	Download changes.....	3-11
3.6	Parameterization memory and Internet Explorer.....	3-12
3.6.1	Internet Explorer FTP function	3-13
3.6.2	Activating/deactivating the FTP server	3-13
3.6.3	Activating/deactivating the HTTP server	3-14
3.7	Activating/deactivating the journaling function	3-15
3.8	Function blocks for handling files in the parameterization memory	3-16
3.9	Function blocks for Ethernet communication	3-17
3.10	Function blocks for PCP communication	3-18
3.11	Alignment	3-19
4	System variables and status information.....	4-1
4.1	General information	4-1
4.2	Status register for local digital inputs and outputs.....	4-1
4.3	Diagnostic status register	4-2
4.4	Diagnostic parameter register.....	4-3
4.5	PROFINET register (ILC 170 ETH 2TX and ILC 190 ETH 2TX)	4-4
4.6	IEC -61131 runtime system	4-5
4.7	Control processor	4-6
4.8	Battery, realtime clock	4-7
4.9	Power supplies	4-7
4.10	Mode selector switch.....	4-7
4.11	System time.....	4-7
5	Technical data and ordering data	5-1
5.1	Technical data	5-1
5.2	Ordering data	5-8
5.2.1	Modules	5-8
5.2.2	Accessories	5-8
5.2.3	Software	5-8
5.2.4	Documentation	5-8

A	Appendix: Service and maintenance	A-1
	A 1 Error causes and remedies.....	A-1
	A 2 Updating the Inline controller firmware	A-1
	A 3 Connecting unshielded cables	A-2
B	Index.....	B-1

1 Introduction

1.1 Purpose of this manual

This manual helps you to start up and operate the following Inline controllers:

- ILC 130 ETH,
- ILC 150 ETH,
- ILC 155 ETH,
- ILC 170 ETH 2TX or
- ILC 190 ETH 2TX.

1.2 Hardware and software requirements

HW/SW	Description				
Inline controller	ILC 130 ETH	ILC 150 ETH	ILC 155 ETH	ILC 170 ETH 2TX	ILC 190 ETH 2TX
Parameterization memory, plug-in	No	No	No	For the ordering data, see Section "Accessories" on page 5-8	For the ordering data, see Section "Accessories" on page 5-8
Ethernet cable	Ethernet cable for connecting the Inline controller to a PC				
Connecting cable	Connecting cable for connecting the Inline controller to a PC (V.24 (RS-232) cable, optional)				
Automation software versions (Service Pack = SP)					
PC Worx	≥ 5.20 SP3 ****	≥ 5.10 SP 1 *	≥ 5.20 **	≥ 5.20 SP 2 ***	≥ 6.10 SP 1 *****
PC Worx Express	≥ 5.20 SP 3 ****	≥ 5.20 **	≥ 5.20 **	≥ 5.20 SP 2 ***	≥ 6.10 SP 1 ***

* Part of the AUTOMATIONWORX Software Suite 2007 1.30 Service Pack 1

** Part of the AUTOMATIONWORX Software Suite 2008 1.40

*** Part of the AUTOMATIONWORX Software Suite 2008 1.40 Service Pack 2

**** Part of the AUTOMATIONWORX Software Suite 2008 1.40 Service Pack 3

***** Part of the AUTOMATIONWORX Software Suite 2007 1.60 Service Pack 1



For the ordering data for hardware, software, and additional documentation, please refer to Section "Technical data and ordering data" on page 5-1.

PROFINET IO device functions



ILC 170 ETH 2TX and ILC 190 ETH 2TX

Please observe that the PROFINET IO device functions of these controllers are only available with the following software versions or later:

ILC 170 ETH 2TX	PC Worx Version 6.00 Service Pack 2 or later (part of the AUTOMATIONWORX Software Suite 2009 1.50 Service Pack 2)
ILC 190 ETH 2TX	PC Worx Version 6.10 Service Pack 1 or later (part of the AUTOMATIONWORX Software Suite 2010 1.60 Service Pack 1)

The PC Worx Express software does not support this function.

2 Description of the Inline controller

2.1 General description of the Inline controller

The Inline controller is a compact controller with integrated Ethernet and INTERBUS connections.



The ILC 130 ETH, ILC 150 ETH, ILC 155 ETH, ILC 170 ETH 2TX, and ILC 190 ETH 2TX Inline controllers have the same appearance and numerous identical functions.

The main difference lies in the varying memory sizes, which are available to the user.

The ILC 150 ETH and ILC 155 ETH Inline controllers are approved for use in zone 2 potentially explosive areas. Observe the notes in Section 2.3 on page 2-7.

The ILC 170 ETH 2TX and ILC 190 ETH 2TX Inline controllers also have a second Ethernet interface and a slot for an SD memory card (parameterization memory).

In the following, the term Inline controller is used in general. Differences between the various controllers are particularly mentioned where necessary.

For additional information about the different memory sizes, please refer to Section 5.1, "Technical data" from page 5-1 onwards.

IEC 61131 control performance

The Inline controller is continuously configured and programmed in accordance with IEC 61131 using the automation software PC Worx. PC Worx can be operated via the network (Ethernet). The powerful processor can be programmed in all five IEC 61131 programming languages and ensures quick control task processing.

Integrated Ethernet connection

The integrated Ethernet connection (using twisted pair cable) provides for the Ethernet connectivity. Throughout the Ethernet network, the Inline controller can be accessed via Ethernet and TCP/IP or UDP/IP. A standardized Ethernet interface is available for each of the ILC 130 ETH, ILC 150 ETH, and ILC 155 ETH Inline controllers. The ILC 170 ETH 2TX and ILC 190 ETH 2TX controllers have two fully implemented Ethernet connections, which are switched inside the device.

Integrated communication functions enable direct and effective data exchange via Ethernet. The Ethernet network provides universal options for communicating with the Inline controller. Using the send and receive communication blocks, information, e.g., necessary coupling variables, can be exchanged between Inline controllers via Ethernet. This enables distributed, modular automation solutions to be configured.

The existing IEC 61131-5 blocks have thus been extended to include a transparent TCP/IP mode and a transparent UDP/IP mode.

When using the AX OPC server provided in the AUTOMATIONWORX Software Suite Version 1.30 or later, Inline controller data is available in the Ethernet network in a standardized format and can be used for the different visualization Inline packages.

PROFINET IO device functions (ILC 170 ETH 2TX and ILC 190 ETH 2TX)

The PROFINET protocol can additionally be used via the Ethernet interfaces of the ILC 170 ETH 2TX and ILC 190 ETH 2TX Inline controllers. In this case, the Inline controllers can be used as a PROFINET IO device. This function is only available with the following device and software versions or later:

ILC 170 ETH 2TX	Hardware "02"/Firmware "3.5x" or later, together with the PC Worx software, Version 6.00 Service Pack 2 or later
ILC 190 ETH 2TX	Hardware "00"/Firmware "3.70" or later, together with the PC Worx software, Version 6.10 Service Pack 1 or later



Please refer to Section "ILC 170 ETH 2TX (ILC 190 ETH 2TX) as a PROFINET IO device" on page 3-5 for information on how to configure the ILC 170 ETH 2TX or ILC 190 ETH 2TX Inline controllers as a PROFINET IO device with the PC Worx software.

Integrated INTERBUS connection

An Inline local bus as well as an INTERBUS remote bus can be connected via the INTERBUS connection. In this way you can create a complete INTERBUS system (maximum of 4 remote bus levels) using the Inline controller as the distributed control system.

The I/O level is connected to the Inline controller using INTERBUS.



Please note that the ILC 130 ETH does not support connection of the INTERBUS remote bus.

V.24 (RS-232) interface

This interface can be used to **either** assign the IP address of the Inline controller and to access the controller using the Diag+ diagnostic tool **or** to communicate with serial I/O devices via function blocks.



The Inline controller cannot be programmed via the V.24 (RS-232) interface.

Parameterization memory/SD card (ILC 170 ETH 2TX and ILC 190 ETH 2TX)

The ILC 170 ETH 2TX and ILC 190 ETH 2TX Inline controllers have a plug-in parameterization memory in the form of an SD card. This memory can be used to save programs and configurations, which belong to your project, e.g., the visualization project.



The parameterization memory is not supplied as standard with the ILC 170 ETH 2TX and ILC 190 ETH 2TX Inline controllers. Use only a parameterization memory provided by Phoenix Contact (for the ordering data, see Section "Accessories" on page 5-8).



NOTE: Parameterization memory (SD card) – formatting note

The SD card is preformatted and designed for use with Phoenix Contact devices. Ensure that the SD card is not reformatted.

2.2 Possible fields of application of the Inline controller

2.2.1 ILC 130 ETH

The **ILC 130 ETH** Inline controller can be used as a distributed control system of an Inline station, which is connected to an Ethernet system. An Inline local bus (Figure 2-1) can then be connected to the Inline controller.

Inline local bus




Figure 2-1 Connected Inline local bus



Please note that the ILC 130 ETH does not support connection of the INTERBUS remote bus.

2.2.2 ILC 150 ETH, ILC 155 ETH, ILC 170 ETH 2TX, and ILC 190 ETH 2TX

The Inline controllers (ILC 150 ETH/ILC 155 ETH/ILC 170 ETH 2TX/ILC 190 ETH 2TX) can be used as a distributed control system of an Inline station, which is connected to an Ethernet system. A single Inline local bus (Figure 2-2) as well as a complete INTERBUS system with a maximum of 4 remote bus levels (Figure 2-3) can be connected to the Inline controller.

Inline local bus




Figure 2-2 Connected Inline local bus

Remote bus levels




Figure 2-3 Remote bus levels

7805C005

2.2.3 ILC 170 ETH 2TX and ILC 190 ETH 2TX as a PROFINET IO device in a PROFINET network

The following figure shows the example of a ILC 170 ETH 2TX as a PROFINET IO device in a PROFINET network.




Figure 2-4 PROFINET IO device using the example of the ILC 170 ETH 2TX

Key:

- A PROFINET IO controller (in the example RFC 470 PN 3TX Remote Field Controller)
- B Managed switch
- C PROFINET IO device (in the example: ILC 170 ETH 2TX)



For additional information on how to integrate the ILC 170 ETH 2TX and ILC 190 ETH 2TX Inline controllers as a PROFINET IO device in a PROFINET network, please refer to Section "ILC 170 ETH 2TX (ILC 190 ETH 2TX) as a PROFINET IO device" on page 3-5.

2.2.4 Applicative system redundancy with ILC 170 ETH 2TX or ILC 190 ETH 2TX

The following figure shows an example of applicative system redundancy. The example shows an IO device with control function (ILC 170 ETH 2TX) that is connected with a switch to a PROFINET network. Identical application programs run on both higher-level IO controllers. To achieve synchronization both IO controllers are connected with a switch over an Ethernet connection. IO controller A functions as a primary IO controller, IO controller B functions as a backup IO controller.

The ILC 190 ETH 2TX also supports applicative system redundancy.

Controllers with applicative (programmed) redundancy

Network redundancy with Media Redundancy Protocol (MRP)

IO devices with Phoenix Redundancy Layer




Figure 2-5 Applicative system redundancy – An example



For further information on applicative system redundancy, please refer to the AH EN APPLICATIVE SYSTEM REDUNDANCY. This application note can be downloaded at www.phoenixcontact.net/catalog.

- A Primary IO controller (in the example: RFC 470 PN 3TX Remote Field Controller)
- B Backup IO controller (in the example: RFC 470 PN 3TX Remote Field Controller)
- C Managed switches
- D IO device with control function (in the example: ILC 170 ETH 2TX with IO device function and Phoenix Redundancy Layer)

2.3 Notes on using the Inline controller (ILC 150 ETH/ILC 155 ETH) in potentially explosive areas

Approval according to EC directive 94/9 (ATEX) II 3G Ex nAC II T4 X

The Inline controller (ILC 150 ETH/ILC 155 ETH) conforms to the requirements of protection type "n" and can be installed in a zone 2 potentially explosive area. The Inline controller (ILC 150 ETH/ILC 155 ETH) is a category 3G item of electrical equipment.



WARNING: Explosion hazard

Only Inline terminals that are approved for use in potentially explosive areas may be snapped onto the Inline controller.

Before using an Inline terminal in a zone 2 potentially explosive area, first check that the terminal has been approved for installation in this area.

For a list of terminals approved for zone 2 potentially explosive areas, please refer to the AH EN IL EX ZONE 2 application note.

Check the labeling on the Inline terminal and the packaging (see Figure 2-6).



Figure 2-6 Typical labeling of terminals for use in potentially explosive areas



WARNING: Explosion hazard

Prior to startup, make sure that the following points and instructions are observed.

1. When working on the Inline controller, always disconnect the supply voltage.
2. The Inline controller must only be installed, started up, and maintained by qualified specialist personnel.
3. Mount the Inline controller in a control cabinet or metal housing. The minimum requirement for both items is IP54 protection according to EN 60529.
4. The Inline controller must not be subject to mechanical strain and thermal loads, which exceed the limits specified in the product documentation.
5. The Inline controller must not be repaired by the user. Repairs may only be carried out by the manufacturer. The Inline controller is to be replaced by an approved controller of the same type.
6. Only category 3G equipment may be connected to Inline controllers in zone 2.
7. Observe all applicable standards and national safety and accident prevention regulations for installing and operating equipment.

Restrictions



WARNING: Explosion hazard

When using the controller in potentially explosive areas, observe the technical data and limit values specified in the corresponding documentation (user manual, package slip).



WARNING: Explosion hazard, restrictions regarding the Inline system

- Please make sure that the **maximum permissible current of 4 A** flowing through potential jumpers U_M and U_S (total current) is not exceeded when using the Inline terminals in potentially explosive areas.

2.4 Unpacking the Inline controller

The Inline controller is supplied in an ESD bag together with a package slip with installation instructions. Please read the complete package slip carefully before unpacking the Inline controller.



NOTE: Electrostatic discharge

The Inline controller contains components, which may be damaged or destroyed by electrostatic discharge. When handling the Inline controller, observe the necessary safety precautions against electrostatic discharge (ESD) according to EN 61340-5-1.




NOTE:

To avoid possible damage to the Inline controller, unpack and pack the controller in accordance with the ESD regulations.

2.5 Connection and operating elements

ILC 130 ETH, ILC 150 ETH,
ILC 155 ETH



7805A006

Figure 2-7 Structure of the Inline controller (ILC 130 ETH, ILC 150 ETH, ILC 155 ETH; shown in the figure: ILC 150 ETH)

The Inline controller consists of the following components:

- 1 Electronics base
- 2 Mode selector switch
- 3 Reset button
- 4 V.24 (RS-232) interface
- 5 Ethernet connection
- 6 Connector 1: terminal points for voltage supply
- 7 Connector 2: output terminal points
- 8 Connectors 3 and 4: input terminal points
- 9 Diagnostic and status indicators
- 10 End plate

ILC 170 ETH 2TX,
ILC 190 ETH 2TX




Figure 2-8 Structure of the Inline controller (ILC 170 ETH 2TX, ILC 190 ETH 2TX; shown in the figure: ILC 170 ETH 2TX)

The Inline controller consists of the following components:

- 1 Electronics base
- 2 Slot for the parameterization memory/card holder (SD card).



The SD card is not supplied as standard with the ILC 170 ETH 2TX/ILC 190 ETH 2TX Inline controllers.

Please refer to the ordering data in Section “Accessories” on page 5-8.

- 3 Mode selector switch
- 4 Reset button
- 5 V.24 (RS-232) interface (X1)
- 6 Ethernet interfaces (X2.1/X2.2)
- 7 Connector 1: terminal points for voltage supply
- 8 Connector 2: output terminal points
- 9 Connectors 3 and 4: input terminal points
- 10 Diagnostic and status indicators
- 11 End plate

2.6 Diagnostic and status indicators




The descriptions for diagnostic and status indicators apply to all the Inline controllers listed on the inner cover page of this manual.


The diagnostic and status indicators are used for quick local error diagnostics.

ILC 170 ETH 2TX /
ILC 190 ETH 2TX:


PLC/PWR
PN



PLC/PWR




I2




ETH



I1



O1



7805C007

Figure 2-9 Diagnostic and status indicators

Local diagnostic and status indicators

Des.	Color	Status	Meaning
ETH: State of the Ethernet interface (applies to both interfaces (X2.1, X2.2) for the ILC 170 ETH 2TX/ILC 190 ETH 2TX)			
LNK	Green	OFF	Connection not established successfully
		ON	Connection established successfully (link): The Inline controller is able to contact another network device.
ACT	Yellow	OFF	Data transmission inactive
		ON	Data transmission (activity): The Ethernet interface transmits or receives data.
PROFINET: (ILC 170 ETH 2TX/ILC 190 ETH 2TX)			
BF	Red	Status of PROFINET IO communication/communication error (BusFail)	
		OFF	The PROFINET IO controller has established an active communication connection to at least one PROFINET IO device.
		ON	No PROFINET IO communication available (no link status at the Ethernet ports).
		Flashing	No communication connection to the PROFINET IO controller, the connection is being established. Link status available.
SF	Red	System failure (PROFINET)	
		OFF	PROFINET diagnostics not present.
		ON	PROFINET diagnostics present.

Des.	Color	Status	Meaning
PLC: Diagnostics of the Inline controller			
FR	Green		Inline controller running
		OFF	IEC 61131 runtime system not ready to operate.
		Flashing	IEC 61131 runtime system successfully initialized. Control function in READY/STOP state, program not processed.
		ON	IEC 61131 runtime system successfully initialized and a program is running. Control function in RUN state.
FF	Yellow		Failure
		ON	A runtime error has occurred in the IEC 61131 runtime system program
		OFF	No runtime error has occurred in the IEC 61131 runtime system program
FR + FF		Flashing	Applies to ILC 170 ETH 2TX and ILC 190 ETH 2TX only: There is no SD card in the Inline controller.
PWR: Supply voltage (See also Section "Remote bus" on page 2-25)			
UL	Green		24 V supply U_{ILC} for generation of the voltages U_L and U_{ANA}
		OFF	Supply voltage not present
		ON	Supply voltage present (indication if 24 V supply voltage U_{ILC} present)
US	Green		24 V supply for segment circuit
		OFF	Supply voltage not present
		ON	Supply voltage present
UM	Green		24 V supply for main circuit
		OFF	Supply voltage not present
		ON	Supply voltage present
IL: INTERBUS diagnostics			
RDY	Green		INTERBUS master ready to operate/data transmission active (INTERBUS ready/running)
		OFF	INTERBUS master not ready to operate.
		Flashing	INTERBUS master in READY or ACTIVE state.
		ON	INTERBUS master in RUN state.
FAIL	Red		Failure
		OFF	No error occurred
		ON	One of the following errors has occurred: – Bus error in the connected bus (remote bus/local bus) – Controller error
BSA	Yellow		Bus segment aborted
		OFF	Bus segment(s) in the connected bus not switched off.
		ON	One or more bus segments in the connected bus are switched off.

Description of the Inline controller

Des.	Color	Status	Meaning
PF	Yellow		Peripheral fault
		OFF	Peripheral fault on a device in the connected bus
		ON	Peripheral fault of a device in the connected bus (local bus or remote bus)
I/O: Digital inputs and outputs			
I1 to I8	Yellow		Inputs 1 to 8
		OFF	Corresponding input not set
		ON	Corresponding input is set
E	Yellow		Error
		OFF	No short circuit/overload at one of the outputs 1 to 4
		ON	Short circuit/overload at one of the outputs 1 to 4
Q1 to Q4	Yellow		Outputs 1 to 4
		OFF	Corresponding output not set
		ON	Corresponding output is set

2.7 Mode selector switch

The mode selector switch is used to define the operating state of the application program. The RUN/PROG and STOP positions have a toggle button function and the MRESET position a pushbutton function. After releasing the button in the MRESET position, it returns to the STOP position.

Table 2-1 Inline controller operating modes

Operating mode	Explanation
RUN/PROG	<p>The application program is in the RUN state.</p> <p>The PC Worx/PC Worx Express software can be used for program and configuration modifications.</p> <p>The monitoring and online functions can be used.</p>
STOP	The application program is in the STOP state.
MRESET	<p>Retain data and the application program are deleted.</p> <p>Set the mode selector switch in the following sequence to perform deletion of retain data and the application program:</p> <ul style="list-style-type: none"> • Set the switch to the MRESET position for three seconds. • Release the switch for less than three seconds. • Set the switch to the MRESET position for three seconds.




Figure 2-10 Mode selector switch

7406B005

2.8 Reset button (concealed)

The reset button (see item 3 in Figure 2-7 on page 2-9 or item 4 in Figure 2-8 on page 2-10) on the Inline controller can only be operated with a pin and is therefore protected against accidental activation.

If you carry out a voltage reset at the same time as you press the reset button, this resets the Inline controller to its default settings.

Procedure

Hold down the reset button and switch the supply voltage of the Inline controller off and on again. Release the reset button only after the FR (green) and FF (yellow) LEDs flash alternately.

The Inline controller has been initialized successfully and reset to its default settings only after the FR (green) and RDY (green) LEDs are flashing. The control function is in the READY/STOP state, a program is not processed. This procedure can take up to a minute, approximately.

2.9 Parameterization memory

The parameterization memory can be used to save programs and configurations, which belong to your project. In addition, application-specific data can also be stored on the parameterization memory. See also Section "Parameterization memory and Internet Explorer" on page 3-12.

ILC 130 ETH, ILC 150 ETH, ILC 155 ETH

The ILC 130 ETH, ILC 150 ETH, and ILC 155 ETH Inline controllers have an integrated parameterization memory.

ILC 170 ETH 2TX, ILC 190 ETH 2TX

The ILC 170 ETH 2TX and ILC 190 ETH 2TX Inline controllers have a plug-in parameterization memory in the form of an SD card. This plug-in parameterization memory is essential for operating the Inline controller. The parameterization memory is available in the following size.



NOTE: It is not permitted to operate the ILC 170 ETH 2TX and ILC 190 ETH 2TX Inline controllers without parameterization memory.

The parameterization memory is recognized during initialization of the Inline controller. Ensure that the parameterization memory has been inserted before switching on the controller to enable the controller to use it.

Only insert and remove the parameterization memory when the Inline controller supply voltage is disconnected.

The parameterization memory must not be removed during operation of the Inline controller.

Use only a parameterization memory provided by Phoenix Contact (for the ordering data, see Section "Accessories" on page 5-8).



NOTE: Parameterization memory (SD card) – formatting note

The SD card is preformatted and designed for use with Phoenix Contact devices. Ensure that the SD card is not reformatted.

Inserting/removing the parameterization memory




Figure 2-11 Inserting (A) and removing (B) the parameterization memory

Inserting the SD card

The ILC 170 ETH 2TX and ILC 190 ETH 2TX have an SD card holder with push/push technology.

- Insert the parameterization memory (SD card) into the slot as shown in Figure 2-11 (A).
- Applying light pressure, push the parameterization memory into the slot until it engages with a click in the card holder.

Removing the SD card

- Applying light pressure, push the parameterization memory into the slot in the direction shown in Figure 2-11 (B) until the snap-on mechanism releases the parameterization memory and partially ejects it from the slot. Remove the parameterization memory.



For additional information about the parameterization memory, please refer to Section “Parameterization memory and Internet Explorer” on page 3-12.

2.10 Internal basic circuit diagram















Figure 2-12 Internal basic circuit diagram (ILC 170 ETH 2TX)

Key:

	Microprocessor		Converter
	Protocol chip		LED
	V.24 (RS-232) interface		Optocoupler
	Transmitter		NPN transistor
	RJ45 socket		Ethernet switch
	SD card holder (the SD card is not supplied as standard)		

The gray areas in the basic circuit diagram represent electrically isolated areas.:

- A: Ethernet interface
- B: Logic
- C: I/O



Other symbols used are explained in the IL SYS INST UM E user manual.

2.11 Mounting and removing the Inline controller



For notes and instructions on mounting and removing Inline terminals, please refer to the IB IL SYS PRO UM E user manual (for INTERBUS), the IL SYS INST UM E Inline installation manual or the Inline system manual for your bus system.



NOTE:

Before mounting or removing the Inline controller, ensure that the power supply is switched off and cannot be switched on again by unauthorized persons.

An Inline station is set up by mounting the individual components side by side. No tools are required. Mounting the components side by side automatically creates potential and bus signal connections between the individual station components.

The controller is mounted perpendicular to the DIN rail.

Mounting location

Like all other terminals of the Inline product range, the Inline controller has IP20 protection and is designed for use in a closed control cabinet or control box (terminal box) with IP54 protection or higher.

DIN rail

The Inline controller is mounted on a 35 mm standard DIN rail.



Fix the DIN rail, on which the Inline controller is mounted several times, especially in the area around the Inline controller. This makes it easier to remove the Inline controller.

End clamp

Mount end clamps on both sides of the Inline station. The end clamps ensure that the Inline station is correctly mounted. End clamps fix the Inline station on both sides and keep it from moving from side to side on the DIN rail. Phoenix Contact recommends using CLIPFIX 35-5 end clamps (Order No. 3022276).

End plate

The mechanical end of an Inline station is the end plate. It has no electrical function. It protects the station against ESD pulses and the user against dangerous contact voltages. The end plate is supplied together with the Inline controller and does not need to be ordered separately.



NOTE:

When mounting or removing the Inline controller it must be tilted. This means that no Inline terminal should be installed directly to the right of the Inline controller during mounting and removal. The terminal must be removed prior to mounting or removing the Inline controller. Otherwise, the locking clips and jumper contacts will be damaged.

Mounting position

Mount the Inline controller horizontally (as shown in Figure 2-13 on page 2-19). The specified temperature range (see "Ambient conditions" on page 5-6) is only guaranteed if the Inline controller is mounted in this position.

Mounting

When mounting the Inline controller, proceed as shown in Figure 2-13:

- Disconnect the power to the station.
- Place the Inline controller onto the DIN rail from above (A) and push down (B).
- Then attach all the electronics bases required to set up the station. Observe the information provided in the above user manuals.



Ensure that **all** featherkeys and keyways on adjacent terminals are securely interlocked.

- Once all the bases have been snapped on, plug the connectors into the appropriate bases.
First, place the front connector shaft latching in the front snap-on mechanism (C1). Then press the top of the connector towards the base until it snaps into the back snap-on mechanism (C2).




Figure 2-13 Snapping on the Inline controller

Removal

When removing the Inline controller, proceed as shown in Figure 2-15 on page 2-20:

- Disconnect the power to the station.



Unlike other Inline terminals, the Inline controller is removed by tilting it away from the DIN rail. This requires the Inline terminal to the right to be removed prior to removing the Inline controller. The right connector of the Inline controller must also be removed.

Remove the third and fourth connectors to access the right base latch.

It is therefore recommended that all connectors be removed prior to removing the Inline controller.

- If the connectors cause trouble during removal
Remove all the connectors of the Inline controller.
 - Lever up each connector by pressing on the back connector shaft latching (Figure 2-15, A1).
 - Remove the connectors (Figure 2-15, A2).
- If Inline terminals are installed next to the Inline controller (see Figure 2-14):
 - Remove the following connectors:
 - All connectors of the terminal directly connected (A1 to A4)
 - The adjacent connector of the following terminal (B1)
 - Remove the directly adjacent Inline terminal (A).



Observe the information provided in the above user manuals.




Figure 2-14 Connectors to be removed if terminals are installed next to the Inline controller

- Insert a tool in the base latches of the Inline controller and pull gently upwards (Figure 2-15, B). Pull out the Inline controller from the DIN rail (C1, C2).




Figure 2-15 Removing the Inline controller

7406B009

Replacing the Inline controller

If you want to replace an Inline controller within an Inline station, proceed as described above (removing and mounting). Make sure that the terminal to the right is not installed when removing and mounting the Inline controller. Only reinstall this terminal once the Inline controller is mounted.



In particular, make sure that **all** featherkeys and keyways on adjacent terminals are securely interlocked.

Observe the following when replacing an Inline controller:
Enter the new MAC address when using the BootP server.

2.12 Communication paths

The communication path to the Inline controller must be determined before communication with the Inline controller can take place.

The following communication paths are available on the Inline controller:

ILC 130 ETH, ILC 150 ETH, ILC 155 ETH:

(A1) 1 x Ethernet 10/100 BASE-T(X)

ILC 170 ETH 2TX, ILC 190 ETH 2TX:

(A2) 2 x Ethernet X2.1/X2.2: 10/100 BASE-T(X) (switched internally)

ILC 130 ETH, ILC 150 ETH, ILC 155 ETH, ILC 170 ETH 2TX, ILC 190 ETH 2TX:


(B) PRG

The serial interface of your PC is directly connected to the Inline controller (not to the programming).

For additional information about using the serial interface (e.g., IP address assignment), please refer to Section "Serial PRG interface - function blocks" on page 2-24.



The Inline controller cannot be programmed via the V.24 (RS-232) PRG interface.



7805B008

Figure 2-16 Communication paths: (A1/A2) Ethernet (B) PRG

2.12.1 Ethernet

A standardized Ethernet interface each is available for connecting the ILC 130 ETH, ILC 150 ETH, and ILC 155 ETH Inline controllers to the Ethernet network. For the ILC 170 ETH 2TX and ILC 190 ETH 2TX Inline controllers, two standardized Ethernet interfaces (X2.1/X2.2) are available for connection to the Ethernet network.


The Ethernet network is connected via RJ45 female connectors.



Use at least an Ethernet cable according to Cat. 5 of IEEE 802.3.
Observe the bending radii of the Ethernet cables used.


The contact assignment of the interface is as follows:

Transmit data +	T +	1
Transmit data -	T -	2
Receive data +	R +	3
-		4
-		5
Receive data -	R -	6
-		7
-		8



7735A007

Figure 2-17 Ethernet interface



7805B009

Figure 2-18 Connecting the Ethernet cable to the Inline controller
A1: ILC 130 ETH, ILC 150 ETH, ILC 155 ETH
A2: ILC 170 ETH 2TX, ILC 190 ETH 2TX



The interface is able to switch-over the transmitter and receiver automatically (auto crossover).

2.12.2 Serial PRG interface (mini-DIN female connector)

This serial interface providing the Ethernet interface enables communication with the Inline controller from a PC.

A connecting cable is required for connecting the Inline controller to a PC with PC Worx/PC Worx Express via the serial PRG interface.

A connecting cable is required for direct connection of the Inline controller to a PC with PC Worx. Connect the connecting cable to the programming interface of the Inline Controller (designation "PRG") and the serial interface of the PC.



This interface can be used to **either** assign the IP address of the Inline controller and access the Inline controller using the Diag+ diagnostic tool **or** communicate with special I/O devices via function blocks (see Section 2.12.3, "Serial PRG interface - function blocks").

The Inline controller cannot be programmed via the V.24 (RS-232) interface.

Connection




Figure 2-19 Connecting cable between PC and Inline controller



Ordering data:

Connecting cable for connecting the Inline controller to a PC (V.24 (RS-232)) for PC Worx, length 3 m (Designation PRG CAB MINI DIN, Order No. 2730611).

2.12.3 Serial PRG interface - function blocks

This interface can be used for the following:

- Assignment of the IP address or working with Diag+
- Communication with I/O devices via function blocks

The following function blocks are available in the PC Worx/PC Worx Express software:

Table 2-2 Function block overview

Function block	Short description
RS232_INIT	Parameterization of the serial interface You can use this function block to specify the following parameters of the serial interface: <ul style="list-style-type: none"> - Protocol: Transparent - Baud rate: 1200, 2400, 4800, 9600, 19200, 38400, 57600 or 115200 - Data width: 8 data bits, even parity - Number of stop bits: 1 - Hardware flow control: None
RS232_RECEIVE	Reading the internal receive memory of the serial interface
RS232_SEND	Data transmission to the internal transmit memory of the serial interface

Once the RS232_INIT function block has been activated, the interface is parameterized accordingly so that it is only possible to communicate with the connected I/O devices.

Deactivating the RS232_INIT function block or performing another cold restart or warm start enables the IP address to be assigned and the controller to be accessed with Diag+.



For additional information about the function blocks, please refer to the online help for the PC Worx/PC Worx Express software.

I/O devices that can be connected

Various I/O devices (e.g., modem, printer, barcode scanner) can be connected to the controller via the serial PRG interface. The connected devices are addressed from the application program using function blocks.

2.13 INTERBUS



The descriptions for INTERBUS apply to all Inline controllers listed on the inner cover page of this manual.



Observe the information in the "Configuring and installing the Inline product range" user manual IB IL SYS PRO UM E when creating an Inline system (local bus and/or remote bus).



Please note that the Inline controller does not support the following functions:

- Switching of devices
- Single-channel diagnostics
- Fiber optic diagnostics/optical regulation
- Logical addressing

Only INTERBUS devices with SUPI 3 and SUPI 3 OPC protocol chip can be used with INTERBUS as local bus/remote bus devices.

2.13.1 Local bus

The local bus is automatically created by directly connecting I/O modules to the Inline controller.

2.13.2 Remote bus



Please note that the ILC 130 ETH does not support connection of the INTERBUS remote bus.

Connect the remote bus to the Inline controller using one of the following branch terminals. They only differ in the scope of supply.

IBS IL 24 RB-T (Order No. 2727941)

IBS IL 24 RB-T-PAC (Order No. 2861441; including accessories)



The **first branch terminal** must be placed directly after the Inline controller. In terms of topology, it opens a **remote bus**.

If **additional branch terminals** are used after the first branch terminal, they must be installed directly one after the other (see also notes in the terminal-specific data sheet). In terms of topology, the additional branches are **remote bus branches** with the branch terminal being the first device in the corresponding remote bus branch.

A maximum of 3 branch terminals can be connected to the Inline controller, each of which opens a remote bus (see Figure 2-3 on page 2-4).

2.14 Power supply



The descriptions for the power supply apply to all the Inline controllers listed on the inner cover page of this manual.

2.14.1 Sizing of the power supply

Use a power supply unit suitable for the currents in your application. The selection depends on the bus configuration, the resulting maximum currents, and the type of supply (separate supply of U_{ILC} , U_M , and U_S , or supply from a power supply unit).



A power supply without a fall-back characteristic curve must be used for correct operation of the Inline controller (see Figure 2-21). When the Inline controller is switched on, an increased inrush current is temporarily triggered. The Inline controller behaves like a capacitive load when it is switched on.

Some electronically controlled power supplies have a fall-back characteristic curve (see Figure 2-20). They are not suitable for operation with capacitive loads.

A primary switched-mode power supply unit (without fall-back characteristic curve) from the QUINT POWER range (see INTERFACE catalog from Phoenix Contact) is recommended for Inline controller operation.




Figure 2-20 Overload range **with** fall-back characteristic curve




Figure 2-21 Overload range **without** fall-back characteristic curve

2.14.2 Power supply connection

Supply the Inline controller using external 24 V DC voltage sources. The permissible voltage ranges from 19.2 V DC to 30 V DC (ripple included).

The power consumption of the Controller at 24 V is typically 4.8 W (no local bus devices connected).



Only use power supplies that are suitable for operation with capacitive loads (increased inrush current) (see Section "Sizing of the power supply" on page 2-26).

1. Connect the power supplies to the connector for power supply as shown in Figure 2-22.
2. Insert the connector in the Inline controller.
3. Switch on the power supplies.
4. The UL, UM, and US LEDs light up and, after around 10 seconds, the FR and RDY LEDs start flashing.

The Inline controller is now fully initialized.

If the LEDs do not light up or start flashing, there is a serious fault on the Inline controller. In this case, please contact Phoenix Contact.







Figure 2-22 Supply voltage connection

Terminal point	Assignment		Notes
Connector 1	Power connector		
1.1	24 V DC (U _S)	24 V segment voltage supply	The supplied voltage is directly routed to the potential jumper.  NOTE: Protect the supply voltage externally according to the connected load (local bus devices) with 8 A, maximum . Make sure the external fuse blows in any case.
1.2	24 V DC (U _{ILC})	24 V supply	The 7 V communications power (U _L) for the ILC and the connected local bus devices is generated from this voltage. The 24 V analog power (U _{ANA}) for the local bus devices is also generated.  NOTE: Protect the supply voltage externally according to the connected load (local bus devices) with 2 A, maximum . Make sure the external fuse blows in any case.
2.1, 2.2	24 V DC (U _M)	24 V main voltage supply	The main voltage is routed to the local bus devices via the potential jumpers.  NOTE: Protect the supply voltage externally according to the connected load (local bus devices) with 8 A, maximum . Make sure the external fuse blows in any case.
1.3	LGND	Reference potential logic ground	The potential is reference ground for the communications power.
2.3	SGND	Reference potential segment ground	The reference potential is directly led to the potential jumper and is, at the same time, reference ground for the main and segment supply.
1.4, 2.4	FE	Functional earth ground (FE)	Functional earth ground must be connected through the power supply. The contacts are directly connected to the potential jumper and FE springs on the bottom of the housing. The Inline controller is grounded when it is snapped onto a grounded DIN rail. Functional earth ground is only used to discharge interference.



NOTE:

- The **maximum total current** flowing through the potential jumpers is **8 A**.

2.14.3 24 V segment supply/24 V main supply

The segment supply and main supply must have the same reference potential. An electrically isolated voltage area is not possible.

2.14.4 24 V segment supply

There are several ways of providing the segment voltage at connector 1:

1. You can provide the segment voltage separately at the terminal points 1.1 and 2.3 (GND) (see Figure 2-22 on page 2-27).
2. You can jumper connections 1.1 and 2.1 (or 2.2) to ensure that the segment circuit is supplied from the main circuit.
3. You can create a switched segment circuit with a switch between terminal points 1.1 and 2.1 (or 2.2).



NOTE:

The 24 V segment supply has protection against polarity reversal and surge voltage.

It does not have short-circuit protection.

The user must provide short-circuit protection. The rating of the preconnected fuse must be such that the maximum permissible load current of 8 A is not exceeded (total current at U_M and U_S).

2.14.5 24 V main voltage



NOTE:

The 24 V main supply has protection against polarity reversal and surge voltage.

It does not have short-circuit protection.

The user must provide short-circuit protection. The rating of the preconnected fuse must be such that the maximum permissible load current of 8 A is not exceeded (total current at U_M and U_S).

2.14.6 24 V ILC supply



NOTE:

The 24 V ILC supply has protection against polarity reversal and surge voltage. These protective elements are only used to protect the power supply unit.

The rating of the preconnected fuse must be such that the maximum permissible load current of 2 A is not exceeded.

2.14.7 Jumpers




Terminals 1.3 and 2.3 on connector 1 can be jumpered if the communications power and the segment power are not to be electrically isolated.

2.15 Digital inputs and outputs



The descriptions for digital inputs and outputs apply to all the Inline controllers listed on the inner cover page of this manual.

There are eight 24 V DC inputs and four 24 V DC outputs.



7805A011

Figure 2-23 Assignment of the terminal points of connectors 2 to 4

Table 2-3 Terminal point assignment

Terminal point	Assignment	Notes
Connector 2 Output terminal points		
1.1	Q1	Output 1
2.1	Q2	Output 2
1.2, 2.2	GND	Ground contact for 2 and 3-wire termination
1.3, 2.3	FE	Functional earth ground for 3-wire termination
1.4	Q3	Output 3
2.4	Q4	Output 4
The outputs are supplied with 24 V DC from the segment supply (U_S).		
Connector 3 Input terminal points		
1.1	I1	Input 1
2.1	I2	Input 2
1.2, 2.2	24 V	Supply voltage U_M for 2 and 3-wire termination
1.3, 2.3	GND	Ground contact for 3-wire termination
1.4	I3	Input 3
2.4	I4	Input 4

Table 2-3 Terminal point assignment (continued)


Terminal point	Assignment	Notes
Connector 4	Input terminal points	
3.1	I5	Input 5
4.1	I6	Input 6
3.2, 4.2	24 V	Supply voltage U_M for 2 and 3-wire termination
3.3, 4.3	GND	Ground contact for 3-wire termination
3.4	I7	Input 7
4.4	I8	Input 8



The inputs are supplied with 24 V DC from the main supply (U_M).



The outputs have protection when the ground connection is interrupted and must be wired accordingly.



74060016

Figure 2-24 Basic wiring of an output with a load (L)
(shown using the ILC 150 ETH as an example)



Phoenix Contact recommends that connectors for digital 4-channel or 16-channel Inline terminals are used to connect sensors or actuators in 3-wire termination (not included in the scope of supply, see Section “Accessories” on page 5-8).

3 The Inline controller under PC Worx/PC Worx Express

3.1 Software version

Using the Inline controller requires the following PC Worx/PC Worx Express version or later:

Tabelle 3-1 Software version information

Inline controller	Firmware version					
	≤ 3.7x			≥ 3.9x		
	Software versions (Service Pack = SP, Hotfix = HF)					
	PC Worx	PC Worx Express	AUTOMATIONWORX Software Suite	PC Worx	PC Worx Express	AUTOMATIONWORX Software Suite
ILC 130 ETH	≥ 5.20 SP 3		2008 1.40 SP 3	≥ 6.1 SP 1 HF 1	≥ 6.1 SP 1 HF 1	2010 1.60 SP 1
ILC 150 ETH	≥ 5.10 SP 1	-	2007 1.30 SP 1			
	-	≥ 5.20	2008 1.40			
ILC 155 ETH	≥ 5.20		2008 1.40			
ILC 170 ETH 2TX	≥ 5.20 SP 2		2008 1.40 SP 2			
ILC 190 ETH 2TX	≥ 6.10 SP 1		2010 1.60 SP 1			

PROFINET IO device functions



ILC 170 ETH 2TX and ILC 190 ETH 2TX

Please observe that the PROFINET IO device functions of these controllers are only available with the following software versions or later:

ILC 170 ETH 2TX PC Worx Version 6.00 Service Pack 2 or later (part of the AUTOMATIONWORX Software Suite 2009 1.50 Service Pack 2)

ILC 190 ETH 2TX PC Worx Version 6.10 Service Pack 1 or later (part of the AUTOMATIONWORX Software Suite 2010 1.60 Service Pack 1)

The PC Worx Express software does not support this function.



For information about installing and using PC Worx/PC Worx Express, please refer to the corresponding quick start guide. It can be downloaded at www.phoenixcontact.net/catalog and is supplied with the software.

3.2 Assigning the IP address for the controller/ BootP server



The procedure for assigning the IP address is essentially the same in PC Worx and PC Worx Express for all Inline controllers described in this manual. The following example describes the setting in PC Worx Express for the ILC 150 ETH.

By default upon delivery, the Inline controller has no preset IP address. Initial setting of the IP address can be carried out with the PC Worx/PC Worx Express software manually via the serial interface or by means of a BootP server. The IP address can be changed later via the serial connection or Ethernet using the PC Worx/PC Worx Express software.



The connecting cable (V.24 (RS-232) cable) PRG CAB MINI DIN (Order No. 2730611) is available as an optional accessory for connecting the controller to a PC via the serial interface.

Bootstrap protocol (BootP)

In an Ethernet network, BootP is used to assign an IP address to a BootP client using a BootP server. For this example (default upon delivery for the ILC 150 ETH), the ILC 150 ETH (BootP client) sends a Boot_Request as a broadcast in the network. The MAC address of the transmitter is sent with the Boot_Request to provide unique identification. If the BootP server has been activated in PC Worx Express, PC Worx Express responds with a Boot_Reply. PC Worx Express uses this Boot_Reply to inform the ILC 150 ETH of its IP address and subnet mask. Please ensure that:

- The BootP server knows the MAC address sent by the BootP client
- A corresponding IP address and subnet mask have been assigned in PC Worx Express for the MAC address

Once the IP data has been transferred to the ILC 150 ETH successfully, PC Worx Express sends a corresponding acknowledgment message.

PC/network adapter

To determine whether your network permits the IP settings used in the example project (see Figure 3-3 on page 3-4), proceed as follows:

- In the Windows Control Panel, check the settings for your PC network adapter.
- If necessary, adjust these settings so that the ILC 150 ETH can be accessed in your network using the IP address used in the example project.

If your network does not permit the use of the IP address used in the example project, adjust the settings in the project information accordingly (see Figure 3-3 on page 3-4).



If any modifications are made to the project information that affect the IP settings for the controller, a warning is displayed. However, the modification is not implemented automatically. When a new project is created, the default settings are specified under "IP Settings" (see Figure 3-3 on page 3-4).

Assigning IP settings

To set the IP address in PC Worx/PC Worx Express, proceed as described below.



Please note that by default upon delivery Inline BootP is active on the controller.



The IP address that is assigned here for the controller is also implemented as the IP address for the communication path via TCP/IP.



After assigning the IP address, PC Worx Express automatically creates a link via TCP/IP as a communication path to the Inline controller.

- Establish an Ethernet connection between your PC and the controller.
- In the PC Worx Express menu bar, select the "Extras, BootP/SNMP/TFTP-Configuration ..." menu.




Figure 3-1 "Extras, BootP/SNMP/TFTP Configuration..." menu

- Activate the "BootP Server active" checkbox.





Figure 3-2 "BootP Server active" checkbox



- Switch to the bus configuration workspace.
- Select the controller node (here: "ILC 150 ETH").
- Select the "IP Settings" tab in the "Device Details" window.
- Enter the MAC address of the controller (see Figure 3-3 on page 3-4). It is printed on the device and starts with 00.A0.45.



7805A012




Figure 3-3 Entering the MAC address

- Perform a cold restart for the controller. To do this, switch the supply voltage off and then on again after about 2 seconds.

The controller is assigned the IP address, which is specified in the project for the controller. The following message appears in the message window in the "Bus Configurator" tab.




Figure 3-4 Message window following BootP

The IP address is now permanently stored on the controller Flash memory.



For additional information about setting the IP address with PC Worx/PC Worx Express, please refer to the quick start guides for the software used, the ILC 130 starter kit, and the ILC 150 construction kit.

3.3 ILC 170 ETH 2TX (ILC 190 ETH 2TX) as a PROFINET IO device



Please note that you can integrate the Inline controllers ILC 170 ETH 2TX and ILC 190 ETH 2TX in the **PC Worx** software as a **PROFINET IO device** only from the version listed in Section "Software version" on page 3-1 onwards.

In the PC Worx Express software you can switch on PROFINET IO device functions of the Inline controllers from the version listed in Section "Software version" on page 3-1 onwards.

This section uses an example to describe how to integrate the ILC 170 ETH 2TX as a PROFINET IO device. This procedure also applies to the ILC 190 ETH 2TX.

Switching on the PROFINET IO device function of the ILC 170 ETH 2TX

You can switch on the PROFINET IO device function, after you have assigned an IP address for the ILC 170 ETH 2TX according to the description given in Section "Assigning the IP address for the controller/ BootP server" on page 3-2 (in the following example: 192.168.0.10).

- Select the "Status IO Device" item in the device details under "Network Settings".
- Under "Settings", select "activated" in the pull-down menu.




Figure 3-5 Network settings: Activating Status IO Device

- Click on "Send".
- In the "Settings Communication Path" dialog confirm with "OK" the suggested IP address or the one you have selected for your application.




Figure 3-6 "Settings Communication Path" dialog box

Successful execution of the service will be displayed in the status window.




Figure 3-7 Status IO Device/Send settings: Service executed successfully

To transfer the network settings you have to reset the IO controller.

- Select the "Ethernet" item in the Device Details window under "Network Settings".
- In the "Activate Network Settings" area click the "Reset Control System" button.




Figure 3-8 Activate Network Settings: Reset Control System

- In the "Settings Communication Path" dialog confirm with "OK" the suggested IP address or the one you have selected for your application.




Figure 3-9 "Settings Communication Path" dialog box

Successful execution of the service will be displayed in the status window.




Figure 3-10 Activate Network Settings: Service executed successfully

Now you can read in the ILC 170 ETH 2TX as a PROFINET device in a PC Worx project.

Integrating the ILC 170 ETH 2TX as a PROFINET IO device



The following section describes how you read the ILC 170 ETH 2TX as a PROFINET device in the PC Worx software.

As an alternative you can create the PC Worx project by selecting the devices from the device catalog. For more information on creating a PC Worx project, please refer to the online help or the software's quick start guide.

The following conditions apply for the example project:

- Higher-level controller; RFC 470 PN 3TX
- Settings of the controller:
 - IP address LAN1.1/1.2: 192.168.0.2
 - Subnet mask: 255.255.255.0
 - PROFINET device name: rfc-470-pn-1-ctrl
- Settings of the ILC 170 ETH 2TX as a PROFINET IO device:
 - IP address 192.168.0.10
 - Subnet mask: 255.255.255.0
 - PROFINET device name: ilc-170-pnd-18-8a-a8

You can read in the ILC 170 ETH 2TX as a PROFINET device after you have done the following:

- Switched on the PROFINET IO device function of the ILC 170 ETH 2TX
- Installed the PROFINET IO controller and the PROFINET devices (ILC 170 ETH 2TX and other IO devices according to your application)
- Created a project in PC Worx
- Configured the PROFINET IO controller according to your application
- Select "Read PROFINET ..." in the PROFINET context menu of the Bus Structure window.




Figure 3-11 Bus Structure: PROFINET context menu "Read PROFINET"

The "Read PROFINET" dialog that opens up, shows the PROFINET devices that have been detected in the connected network.




Figure 3-12 "Read PROFINET" dialog box

- Select the ILC 170 ETH 2TX and insert it as a PROFINET device by clicking on the "Insert" button.
- Close the dialog box by clicking on the "Close" button.

The PROFINET device inserted before will be displayed in the Bus Structure window.




Figure 3-13 ILC 170 ETH 2TX inserted as a PROFINET IO device

The process data of the PROFINET device will be displayed in the Device Details window under the "Process Data" tab.




Figure 3-14 ILC 170 ETH 2TX as a PROFINET IO device: Process Data

The ILC 170 ETH 2TX is now available as a PROFINET IO device in the PC Worx project.

3.4 Setting the realtime clock under PC Worx Express



The procedure for setting the realtime clock is essentially the same in PC Worx and PC Worx Express. The following example describes the setting in PC Worx Express.

The time and date for the internal system clock of the Inline controller can be set under "Extended Settings" in the "Device Details" window with PC Worx Express.



To set the realtime clock, proceed as described in the quick start guide for the PC Worx Express version used.

3.5 Download changes

The "Download Changes" function supports the following Inline controllers from the specified device versions together with the specified versions of the PC Worx/PC Worx Express software tools.

Table 3-2 Version information for "Download Changes"

Inline controller	Firmware version	PC Worx/PC Worx Express
ILC 130 ETH	≥ 3.01	≥ 5.20 Service Pack 3
ILC 150 ETH	≥ 3.54	≥ 6.00
ILC 155 ETH	≥ 3.54	≥ 6.00
ILC 170 ETH 2TX	≥ 3.00	≥ 5.20 Service Pack 2
ILC 190 ETH 2TX	≥ 3.70	≥ 6.10 Service Pack 1

3.6 Parameterization memory and Internet Explorer

To delete files or store user-specific files on the internal parameterization memory, proceed as follows:



The FTP function must be activated in Internet Explorer. See also Section "Internet Explorer FTP function" on page 3-13.

- Switch to the bus configuration workspace in PC Worx.
- Select the control system, e.g., "ILC 150 ETH", in the "Bus Structure" window.
- Select the "Extended Settings" tab in the "Device Details" window.
- Open Internet Explorer from this window by clicking on the "Open FTP folder on device" button.




Figure 3-15 Extended Settings: Open FTP folder on device

The file structure, which is stored in the parameterization memory, is displayed in the Internet Explorer window.



Data may only be copied or deleted in the parameterization memory. Do not edit any files as Internet Explorer does not store modified data.

For the current state to be displayed, update the display after every action by means of the "View, Refresh" command.

3.6.1 Internet Explorer FTP function

- Activate this setting in Internet Explorer under "Tools, Internet Options..., Advanced".




Figure 3-16 Internet Options: Enable folder view for FTP sites

3.6.2 Activating/deactivating the FTP server

To protect the Inline controller against unauthorized access, it may be necessary to deactivate the FTP server. The CPU_Set_Value_Request service with Var ID 0172_{hex} is used for this. This service activates or deactivates the FTP server for the runtime of the firmware. The set FTP server state is stored retentively and mapped to the ETH_SRV_FTP_ACTIVE system variables. This setting is restored the next time the Inline controller is rebooted.

Value range for the CPU_Set_Value_Request service:

Var ID	0172 _{hex}	
Value	0000 _{hex}	Deactivate FTP server
	0001 _{hex}	Activate FTP server




Figure 3-17 Deactivating the FTP server

3.6.3 Activating/deactivating the HTTP server

To protect the Inline controller against unauthorized access, it may be necessary to deactivate the HTTP server. The CPU_Set_Value_Request service with Var ID 0173_{hex} is used for this. This service activates or deactivates the HTTP server for the runtime of the firmware. The set HTTP server state is stored retentively and mapped to the ETH_SRV_HTTP_ACTIVE system variable. This setting is restored the next time the Inline controller is rebooted.

Value range for the CPU_Set_Value_Request service:

Var ID	0173 _{hex}	
Value	0000 _{hex}	Deactivate HTTP server
	0001 _{hex}	Activate HTTP server

3.7 Activating/deactivating the journaling function

The file system of the parameterization memory supports the journaling function. As a result, voltage failures during write processes to the file system are tolerated by the Inline controller, however, the access speed becomes slower.



The journaling function is deactivated by default.

It can be activated or deactivated via the CPU_Set_Value_Request service with VarID 0194.

Value range for the CPU_Set_Value_Request service:

Code	02CB _{hex}	
Var Count	0001 _{hex}	
Var ID	0194 _{hex}	
Value	0001 _{hex}	Activate journaling function
	0000 _{hex}	Deactivate journaling function




Figure 3-18 Activate journaling function

3.8 Function blocks for handling files in the parameterization memory

The function blocks are used to access files from within the application program. Some of the blocks support multiple instantiation. This means that it is possible to work with a number of different files within the same project. The blocks perform the standard functions that are required for typical file access operations.

The FILE_NOTIFY block is available in addition to the blocks for typical file access operations. This block can be used to detect files that have been modified in a directory containing user files. These modifications may include:

- Deletion of one or more files
- Writing one or more new files
- Modification of one or more existing files

Both modifications made to this directory via FTP (remote) and modifications made locally via function blocks or firmware services can be detected.



All file operations are subject to the following restrictions:
 No directory hierarchies are supported. All file operations only affect the root directory of the parameterization memory.

The function blocks are valid for:

Order designation	From hardware version	From firmware version
ILC 130 ETH	01	3.01
ILC 150 ETH	02	2.10
ILC 155 ETH	01	2.04
ILC 170 ETH 2TX	01	3.00
ILC 190 ETH 2TX	00	3.70

Table 3-3 Overview of function blocks

Function block	Short description
FILE_OPEN	Opens a file with a specific name
FILE_CLOSE	Closes a file with a specific handle
FILE_READ	Reads from a file with a specific handle
FILE_WRITE	Writes to a file with a specific handle
FILE_REMOVE	Deletes a file with a specific name
FILE_TELL	Determines the current position of the file pointer in a file
FILE_SEEK	Moves the current file pointer to a new position
FILE_NOTIFY	Displays files that have recently been created, deleted or modified



The function blocks for handling files in the parameterization memory are described in the PC Worx online help.

3.9 Function blocks for Ethernet communication

The function blocks are used to establish Ethernet communication between two communication partners.

The IP communication blocks listed below enable IEC 61131-5-compliant communication between controllers via Ethernet or communication between controllers and Ethernet devices via TCP/IP or UDP/IP.

Implement all time and connection monitoring in the application program.

The function blocks are valid for the Inline controllers listed in the table below in the specified hardware/firmware versions and enable the specified maximum number of TCP/IP or UDP/IP communication connections:

Order designation	Blocks	From hardware version (HW)	From firmware version (FW)	Ethernet connections to other communication partners (maximum)
ILC 130 ETH	IEC 61131-5	01	3.01	8
	TCP/IP			
	UDP/IP			
ILC 150 ETH	IEC 61131-5	00	1.00	8
	TCP/IP		1.00	
	UDP/IP		2.00	
ILC 155 ETH	IEC 61131-5	01	2.04	8
	TCP/IP			
	UDP/IP			
ILC 170 ETH 2TX	IEC 61131-5	01	3.00	8
	TCP/IP	01	3.00	8 (HW 01/FW 3.00) 16 (HW 02/FW 3.54)
UDP/IP				
ILC 190 ETH 2TX	IEC 61131-5	00	3.70	8
	TCP/IP			16
	UDP/IP			

Table 3-4 Overview of function blocks

Function block	Short description
IP_CONNECT	Establishes a connection between two communication partners
IP_USEND	Transmits data to a communication partner
IP_URCV	Receives data from a communication partner



The communication blocks are described in the PC Worx online help. The extensions for the TCP/IP and UDP/IP function blocks are described in the "TCP/UDP COMMUNICATION" application note.

3.10 Function blocks for PCP communication

The function blocks are used to establish PCP communication between the Inline controller and PCP devices on INTERBUS.

The function blocks are valid for the Inline controllers listed in the table below in the specified HW/FW versions and enable the specified maximum number of PCP communication connections:

Order designation	From hardware version (HW)	From firmware version (FW)	Connections to PCP devices (maximum)
ILC 130 ETH	01	3.01	8
ILC 150 ETH	00 02	1.00 3.54	8 16
ILC 155 ETH	01 01	2.04 3.54	8 16
ILC 170 ETH 2TX	01	3.00	16 (HW 01/FW 3.00) 24 (HW 02/FW 3.54)
ILC 190 ETH 2TX	00	3.70	24

Table 3-5 Overview of function blocks

Function block	Short description
PCP_CONNECT	This block can be used to set up communication connections to each PCP device on INTERBUS.
PCP_WRITE	This block enables PCP objects to be written.
PCP_READ	This block enables data to be read from PCP objects.
PCP_SERVER	This block enables PCP service indications to be received and responses to be sent.



The communication blocks are described in the PC Worx online help.

3.11 Alignment

The alignment of the data elements in the Inline controller memory can result in "data gaps" when storing data in the memory. The compiler automatically fills these gaps with padding bytes during the compiler process in order to prevent incorrect processing.

The disadvantage of the "automatic" filling of data gaps becomes apparent when data is transmitted from the Inline controller to another controller. If this controller does not know the memory algorithm of the Inline controller it will interpret the received data incorrectly.

It is therefore useful to program the filling of data gaps in your application program. Data transmissions to other controllers can thus be taken into consideration. For example, use byte arrays with an even number of bytes and/or word arrays in order to avoid data gaps in your application program.

The following should be taken into consideration when creating the program:

- Create data types in flat structures, i.e., do not nest user-defined data types.
- Insert padding bytes manually in order to ensure the uniform size and layout of the data types.
- When inserting padding bytes, please observe the memory alignment method of the controllers used in the application (1-byte, 2-byte or 4-byte alignment).

Program example with data gaps

The following program example shows how data gaps are filled.

```

1  TYPE
2      Struct1 :
3      STRUCT
4          ByteElement : BYTE;
5          WordElement : WORD;
6      END_STRUCT;
7
8      Struct2 :
9      STRUCT
10         WordElement : WORD;
11         ByteElement : BYTE;
12     END_STRUCT;
13
14     Struct3 :
15     STRUCT
16         ByteElement1 : BYTE;
17         ByteElement2 : BYTE;
18     END_STRUCT;
19
20     Struct4 :
21     STRUCT
22         Struct2Element : Struct2;
23         Struct3Element : Struct3;
24     END_STRUCT;
25
26     Array1 : ARRAY [0..1] OF Struct2;
27 END_TYPE

```

Figure 3-19 Example programming




Figure 3-20 Alignment - padding bytes in data gaps

Struct1 receives a padding byte after the ByteElement so that the WordElement is at a WORD address (address that can be divided by 2 leaving no remainder). The alignment of the overall structure is based on the data type used with maximum alignment. In this case the WordElement specifies the alignment.

The size of Struct2 is calculated based on the elements used and the resulting alignment. The corresponding number of padding bytes is inserted so that the size of the data type with the value of the alignment can be divided by 2 leaving no remainder (data type size modulo alignment = 0).

Struct3 does not receive any padding bytes as the maximum alignment corresponds to one byte.

Due to the padding bytes that belong to the Struct2 structure, the Struct3 structure starts at an even address in Struct4.

Array1 receives 2 padding bytes, which corresponds to two consecutive Struct2 structures.

Program example without data gaps

The following program shows an example of how the filling of data gaps may appear in your application program. Fill data gaps, which are to be expected due to the memory alignment, with application data (padding bytes in Figure 3-21).

```

1  TYPE
2  Struct1 :
3  STRUCT
4      ByteElement : BYTE;
5      ByteElement : BYTE; (*Padding-Byte*)
6      WordElement : WORD;
7  END_STRUCT;
8
9  Struct2 :
10 STRUCT
11     WordElement : WORD;
12     ByteElement : BYTE;
13     ByteElement : BYTE; (*Padding-Byte*)
14 END_STRUCT;
15
16 Struct3 :
17 STRUCT
18     ByteElement1 : BYTE;
19     ByteElement2 : BYTE;
20 END_STRUCT;
21
22 STRUCT4 :
23 STRUCT
24     Struct2Element : Struct2;
25     Struct3Element : Struct3;
26 END_STRUCT;
27
28 Array1 : ARRAY [0..1] OF Struct2;
29 END_TYPE

```

Figure 3-21 Example programming with padding bytes

4 System variables and status information

4.1 General information

This section describes the special program functions of the PC Worx/PC Worx Express software that are available for the Inline controller.



The following descriptions of system variables and status information apply to PC Worx and PC Worx Express.

The Inline controller has a register set, which is used for diagnostics and easy control of the bus system. The diagnostic data is stored in the diagnostic status register and the diagnostic parameter register. These registers are available to the application program as system variables (system flags, global variables).

Operating states, error states, and additional information about the INTERBUS system can be evaluated in the application program.



For additional information on diagnostics, please refer to the following user manual:

- INTERBUS diagnostics guide
IBS SYS DIAG DSC UM E

Order No. 2747293

4.2 Status register for local digital inputs and outputs

The following system variables can be used to read the local digital input and output states and to write the local digital output states.

Table 4-1 System variables of the status register for local digital inputs and outputs

System variable	Type	Meaning
ONBOARD_INPUT	WORD	State of all local inputs
ONBOARD_INPUT_BIT0	BOOL	State of local input IN1
ONBOARD_INPUT_BIT1	BOOL	State of local input IN2
ONBOARD_INPUT_BIT2	BOOL	State of local input IN3
ONBOARD_INPUT_BIT3	BOOL	State of local input IN4
ONBOARD_INPUT_BIT4	BOOL	State of local input IN5
ONBOARD_INPUT_BIT5	BOOL	State of local input IN6
ONBOARD_INPUT_BIT6	BOOL	State of local input IN7
ONBOARD_INPUT_BIT7	BOOL	State of local input IN8
ONBOARD_OUTPUT_BIT0	BOOL	State of local output OUT1
ONBOARD_OUTPUT_BIT1	BOOL	State of local output OUT 2
ONBOARD_OUTPUT_BIT2	BOOL	State of local output OUT3
ONBOARD_OUTPUT_BIT3	BOOL	State of local output OUT4
ONBOARD_OUTPUT_OVERLOAD_0_3	BOOL	One local output overloaded

4.3 Diagnostic status register

In the diagnostic status register, information on the operating state of the Inline controller are stored. Every bit in the diagnostic status register is assigned a certain Inline controller state.

The following system variables can be used to read the diagnostic status register information.


Table 4-2 System variables of the diagnostic status register

System variable	Type	Meaning
MASTER_DIAG_STATUS_REG_USER	BOOL	User error/parameterization error
MASTER_DIAG_STATUS_REG_PF	BOOL	Peripheral fault
MASTER_DIAG_STATUS_REG_BUS	BOOL	Bus error
MASTER_DIAG_STATUS_REG_CTRL	BOOL	Error on the Inline controller/hardware fault
MASTER_DIAG_STATUS_REG_DTC	BOOL	Diagnostic routine active
MASTER_DIAG_STATUS_REG_RUN	BOOL	Data transmission active
MASTER_DIAG_STATUS_REG_ACT	BOOL	Selected configuration is ready for operation
MASTER_DIAG_STATUS_REG_RDY	BOOL	Inline controller ready to operate
MASTER_DIAG_STATUS_REG_BSA	BOOL	Bus segment aborted
MASTER_DIAG_STATUS_REG_SYSFAIL	BOOL	System failure
MASTER_DIAG_STATUS_REG_RES	BOOL	Standard function processed negatively
MASTER_DIAG_STATUS_REG_SYNCRES	BOOL	Synchronization error occurred
MASTER_DIAG_STATUS_REG_DCR	BOOL	Faulty data cycles
MASTER_DIAG_STATUS_REG_WARN	BOOL	Defined warning time exceeded
MASTER_DIAG_STATUS_REG_QUAL	BOOL	Defined error density exceeded
MASTER_DIAG_STATUS_REG_SSINFO	BOOL	Pending message
MASTER_DIAG_STATUS_REG_HI	BYTE	Master diagnostic status register, high byte
MASTER_DIAG_STATUS_REG_LOW	BYTE	Master diagnostic status register, low byte

4.4 Diagnostic parameter register

In the diagnostic parameter register, you will find additional information on the error indicated in the diagnostic status register. The following information is stored in the diagnostic parameter register:

- Error location
- Error code



6219A040

Figure 4-1 Error location in the diagnostic parameter register



Special case: If an interface error cannot be located, the value 128 is indicated in the diagnostic parameter register, i.e., bit 7 is set.

The diagnostic parameter register is rewritten whenever an error occurs. The diagnostic parameter register contains the value "0" if no errors are detected.

Table 4-3 System variables of the diagnostic parameter register

System variable	Type	Meaning
MASTER_DIAG_PARAM_REG_HI	BYTE	Diagnostic parameter register, high byte
MASTER_DIAG_PARAM_REG_LOW	BYTE	Diagnostic parameter register, low byte
MASTER_DIAG_PARAM_2_REG_HI	BYTE	Extended diagnostic parameter register, high byte
MASTER_DIAG_PARAM_2_REG_LOW	BYTE	Extended diagnostic parameter register, low byte

4.5 PROFINET register (ILC 170 ETH 2TX and ILC 190 ETH 2TX)



Please observe that the following PROFINET registers are only available when you use Inline controllers with the specified device version and the following software versions or later:

ILC 170 ETH 2TX Hardware "02"/Firmware "3.50"
 PC Worx Version 6.00 Service Pack 2 or later (part of the
 AUTOMATIONWORX Software Suite 2009 1.50 Service Pack 2)

ILC 190 ETH 2TX Hardware "00"/Firmware "3.70"
 PC Worx Version 6.10 Service Pack 1 or later (part of the
 AUTOMATIONWORX Software Suite 2010 1.60 Service Pack 1)

The PC Worx Express software does not support this function.

Table 4-4 PROFINET system variables (PROFINET IO device function)

System variable	Type	Meaning
PND_S1_PLC_RUN	BOOL	Status of the higher-level control system/ IO controllers
PND_S1_VALID_DATA_CYCLE	BOOL	The higher-level control system/ IO controller has established the connection.
PND_S1_OUTPUT_STATUS_GOOD	BOOL	IOP status of the higher-level control system/ IO controller
PND_S1_DATA_LENGTH	WORD	Process data length that was configured for the IO device.
PND_S1_OUTPUTS	PND_IO_256	OUT process data Memory area for OUT process data that the IO device sends to the higher-level control system/ IO controller.
PND_S1_INPUTS	PND_IO_256	IN process data Memory area for IN process data that the IO device receives from the higher-level control system/ IO controller.
PND_IO_DRIVEN_BY_PLC	INT	Applicative system redundancy: Information from which higher-level IO controller the data in the IO device comes from (cf. Figure 2-5 on page 2-6). 0: No IO controller 1: Controller A 2: Controller B

4.6 IEC -61131 runtime system

There is a separate group of variables for the IEC 61131 runtime system.

Table 4-5 System variables of the IEC 61131 runtime system

System variable	Type	Meaning
PLCMODE_ON	BOOL	PLC status ON: The runtime system on the Inline controller is ready to operate.
PLCMODE_RUN	BOOL	PLC status OPERATION: The application program is running.
PLCMODE_STOP	BOOL	PLC status STOP: The application program is currently not running.
PLCMODE_HALT	BOOL	PLC status HALT: The application program was stopped at an unspecified point.
PLCDEBUG_BPSET	BOOL	Breakpoint set: At least one breakpoint has been set in the application program.
PLCDEBUG_FORCE	BOOL	Variable(s) forced: At least one variable is being continuously overwritten (forced).
PLCDEBUG_POWERFLOW	BOOL	Powerflow ON: In "Powerflow" mode, you can see which parts of your application program are being processed. This bit indicates whether "Powerflow" mode is active.
PLC_TICKS_PER_SEC	INT	System ticks per second: This variable shows how many pulses the system clock of the Inline controller delivers per second.
PLC_SYS_TICK_CNT	DINT	Number of system ticks: This variable shows the total number of pulses delivered by the system clock since the last startup.
PLC_TASK_AVAILABLE	INT	Number of available PLC tasks
PLC_SYSTASK_AVAILABLE	INT	Number of available system tasks
PLC_MAX_ERRORS	DINT	Maximum number of "errors, warnings and logging events" If this maximum number is reached, the controller is stopped.
PLC_ERRORS	DINT	Number of "errors, warnings and logging events" currently entered.
PLC_TASK_DEFINED	INT	Number of tasks used
PLC_TASK_1	Record, elements = 17	Information on task 1
:	:	:
PLC_TASK_8	Record, elements = 9	Information on task 8

4.7 Control processor

The system variables listed below show the states of the diagnostic status register on the control processor of the Inline controller.

Table 4-6 System variables of the control processor

System variable	Type	Meaning
COP_DIAG_STATUS_REG_RT_ERR	BOOL	A runtime error (out of realtime) has occurred on the control processor.
COP_DIAG_STATUS_REG_FAT_ERR	BOOL	A fatal error has occurred on the control processor. Division by zero, for example, leads to a fatal error.
COP_DIAG_STATUS_REG_WARN	BOOL	A warning has been issued on the control processor.
COP_DIAG_STATUS_REG_PON	BOOL	Power ON (COP): The control processor is ready to operate.
COP_DIAG_STATUS_REG_FC_RUN	BOOL	Runtime system RUN
COP_DIAG_STATUS_REG_FC_STOP	BOOL	Runtime system STOP
COP_DIAG_STATUS_REG_FC_HALT	BOOL	Runtime system HALT
COP_DIAG_STATUS_REG_FC_LDG	BOOL	Runtime system LOADING
COP_DIAG_STATUS_REG_FC_DBG	BOOL	Runtime system DEBUG
COP_DIAG_STATUS_REG_FC_RDO	BOOL	Runtime system READONLY
COP_DIAG_PARAM_REG	WORD	Diagnostic parameter register of the control processor
COP_DIAG_PARAM_2_REG	WORD	Extended diagnostic parameter register of the control processor

The system variable given below shows status information of the control processor of the Inline controller.

Table 4-7 System variable of the control processor

System variable	Type	Meaning
COP_CPU_LOAD_WARNING	BOOL	The control processor is reaching the limits of its capacity.

4.8 Battery, realtime clock

Table 4-8 System variables of the battery and realtime clock

System variable	Type	Meaning
RTC_BATTERY_LOW	BOOL	The realtime clock battery is low.
RTC_DATA_INVALID	BOOL	Realtime clock data is invalid.

4.9 Power supplies

Table 4-9 System variables of the power supplies

System variable	Type	Meaning
POWER_SUPPLY_MAIN_OK	BOOL	The 24 V main power supply is OK.
POWER_SUPPLY_INPUTS_OK	BOOL	The 24 V power supply for the local inputs is OK.
POWER_SUPPLY_OUTPUTS_0_3_OK	BOOL	The 24 V power supply for the local outputs is OK. (Bits 0 to 3)

4.10 Mode selector switch

Table 4-10 System variables of the mode selector switch

System variable	Type	Meaning
KEY_SWITCH_RESET	BOOL	The mode selector switch is in the MRESET position.
KEY_SWITCH_STOP	BOOL	The mode selector switch is in the STOP position.
KEY_SWITCH_RUN_PROG	BOOL	The mode selector switch is in the RUN_PROG position.

4.11 System time


Table 4-11 System variables of the system time

System variable	Type	Meaning
RTC_HOURS	INT	System time (hours)
RTC_MINUTES	INT	System time (minutes)
RTC_SECONDS	INT	System time (seconds)
RTC_DAY	INT	System time (day)
RTC_MONTH	INT	System time (month)
RTC_YEAR	INT	System time (year)

5 Technical data and ordering data

5.1 Technical data

General data	
Dimensions	80 mm x 119.8 mm x 71.5 mm
Weight	285 g, approximately (ILC 130 ETH, ILC 150 ETH, ILC 155 ETH) 295 g, approximately (ILC 170 ETH 2TX, ILC 190 ETH 2TX)
Connection data for connectors	
Connection method	Spring-cage connection
Conductor cross-section	
Single-wire/terminal point, solid	0.08 mm ² to 1.5 mm ²
Single-wire/terminal point, stranded	0.08 mm ² to 1.5 mm ²
Single-wire/terminal point, AWG	28 to 16
	We recommend using a conductor cross-section of 0.2 mm ² to 1.5 mm ² .

General supply	
	Use a power supply without fall-back characteristic curve (see Section "Sizing of the power supply" on page 2-26).

24 V main supply (U _M)	
Connection method	Spring-cage terminals
Nominal value	24 V DC
Tolerance	-15%/+20% (according to EN 61131-2)
Ripple	±5%
Current consumption at nominal voltage (typical)	6 mA + 7 mA for each input set
Current consumption at nominal voltage (maximum)	8 A DC
Continuation	Via potential routing
Protective measures	
Surge voltage	Input protective diodes (can be destroyed by permanent overload) Pulse loads up to 1500 W are short circuited by the input protective diode.
Polarity reversal	Parallel diodes for protection against polarity reversal; in the event of an error the high current flowing through the diodes causes the preconnected fuse to blow.



NOTE:

Provide external fuses for this 24 V area. The power supply unit must be able to supply 4 times (400%) the nominal current of the external fuse, to ensure that the fuse blows safely in the event of an error.

24 V segment supply U_S

Connection method	Spring-cage terminals
Nominal value	24 V DC
Tolerance	-15%/+20% (according to EN 61131-2)
Ripple	±5%
Current consumption at nominal voltage (typical)	10 mA + 10 mA for each output set + load
Current consumption at nominal voltage (maximum)	8 A
Continuation	Through potential routing
Protective measures	
Surge voltage	Input protective diodes (can be destroyed by permanent overload) Pulse loads up to 1500 W are short circuited by the input protective diode.
Polarity reversal	Parallel diodes for protection against polarity reversal; in the event of an error the high current flowing through the diodes causes the preconnected fuse to blow.



NOTE:

Provide external fuses for this 24 V area. The power supply unit must be able to supply 4 times (400%) the nominal current of the external fuse, to ensure that the fuse blows safely in the event of an error.

24 V supply U_{ILC}

Connection method	Spring-cage terminals
Nominal value	24 V DC
Tolerance	-15%/+20% (according to EN 61131-2)
Ripple	±5%
Permissible range	19.2 V DC to 30 V DC
Current consumption at nominal voltage (minimum)	80 mA (no-load operation, i.e., no local bus devices connected, bus inactive)
Current consumption at nominal voltage (typical)	210 mA
Current consumption at nominal voltage (maximum)	870 mA (370 mA communications power + 500 mA analog power supply)
Protective measures	
Surge voltage	Input protective diodes (can be destroyed by permanent overload) Pulse loads up to 1500 W are short circuited by the input protective diode.
Polarity reversal	Serial diode in the lead path of the power supply unit; in the event of an error only a low current flows. In the event of an error, no fuse trips within the external power supply unit



NOTE:

Observe the current consumption of the Inline terminals


Observe the logic current consumption of each device when configuring an Inline station. It is specified in every terminal-specific data sheet. The current consumption can differ depending on the individual terminal. The permissible number of devices that can be connected therefore depends on the specific station structure.

Protection of the external power supply unit

Ensure protection of 2 A by fuses through the external power supply unit.

7.5 V communications power U_L (potential jumper)

Nominal value	7.5 V DC
Tolerance	±5%
Ripple	±1.5%
Maximum output current	0.8 A DC, observe derating (internally protected against short circuit)
Derating	



24 V analog supply U_{ANA} (potential jumper)

Nominal value	24 V DC
Tolerance	-15% / +20%
Ripple	±5%
Maximum output current	0.5 A DC, observe derating
Protective measures	Electric short-circuit protection

PROFINET (ILC 170 ETH 2TX and ILC 190 ETH 2TX)

Type	PROFINET IO device
Specification	2.2
Performance class	RT
Update rate	≥ 1 ms
Number of slots	1
Vendor ID	
ILC 170 ETH 2TX	00B0 _{hex} / 176 _{dec}
ILC 190 ETH 2TX	00B0 _{hex} / 176 _{dec}
Device ID	
ILC 170 ETH 2TX	0035 _{hex} / 53 _{dec}
ILC 190 ETH 2TX	0076 _{hex} / 118 _{dec}

INTERBUS

Number of I/O points	4096, maximum
Number of data words	256, maximum
Transmission speed	500 kbps or 2 Mbps



This speed is automatically set according to the connected Inline terminals. Only use terminals with a uniform transmission speed in the entire connected Inline system (local bus and remote bus).

Transmission reliability	CR check (hamming distance: 4)
Protocol	EN 50254

Number of devices in the INTERBUS system

Total number of bus devices	
ILC 130 ETH	63, maximum
ILC 150 ETH, ILC 155 ETH, ILC 170 ETH 2TX, ILC 190 ETH 2TX	128, maximum
Number of remote bus devices	
ILC 130 ETH	–
ILC 150 ETH, ILC 155 ETH, ILC 170 ETH 2TX, ILC 190 ETH 2TX	32, maximum
Number of devices with parameter channel (PCP)	
ILC 130 ETH,	8
ILC 150 ETH,	8 (HW/FW: ≥ 00/1.00), 16 (HW/FW: ≥ 02/3.54)
ILC 155 ETH,	8 (HW/FW: ≥ 01/2.04), 16 (HW/FW: ≥ 01/3.54)
ILC 170 ETH 2TX	16 (HW/FW: ≥ 01/3.00), 24 (HW/FW: ≥ 02/3.54)
ILC 190 ETH 2TX	24
Number of remote bus levels	
ILC 130 ETH	–
ILC 150 ETH, ILC 155 ETH, ILC 170 ETH 2TX, ILC 190 ETH 2TX	4, maximum



Please note that the ILC 130 ETH does not support connection of the INTERBUS remote bus.

Network interface

Type	
ILC 130 ETH, ILC 150 ETH, ILC 155 ETH	1 x Ethernet; 10 BASE-T and 100 BASE-T(X)
ILC 170 ETH 2TX, ILC 190 ETH 2TX	2 x Ethernet; 10 BASE-T and 100 BASE-T(X)
Transmission speed	10 Mbps (10 BASE-T), 100 Mbps (100 BASE-T(X)) half duplex, full duplex, auto negotiation



This speed cannot be set manually. It is set automatically by means of auto negotiation.

Connection method	CAT5 twisted-pair cable Twisted-pair cable with a conductor cross-section of 0.14 mm ² to 0.22 mm ² 8-pos. RJ45 female connector
-------------------	--

Inline local bus

Interface	Inline local bus
Electrical isolation	No
Number of devices	
ILC 130 ETH	63, maximum
ILC 150 ETH, ILC 155 ETH, ILC 170 ETH 2TX, ILC 190 ETH 2TX	128, maximum



NOTE: Observe the current consumption of the Inline terminals

Observe the logic current consumption of each device when configuring an Inline station. It is specified in every terminal-specific data sheet. The current consumption can differ depending on the individual terminal. The permissible number of devices that can be connected therefore depends on the specific station structure.

Diagnostic interface

Connection method	6-pos. mini-DIN female connector (PS/2)
Interface type	RS-232
Transmission rate	9600 baud
Electrical isolation	No

Digital inputs

Number	8
Input design	According to EN 61131-2 Type 1
Definition of the switching threshold	
Maximum low-level voltage	5 V DC
Minimum high-level voltage	15 V DC
Nominal input voltage	24 V DC
Permissible range	-0.5 V < U _{IN} < +30 V DC
Nominal input current at 24 V	7 mA, typical; 15mA, maximum
Hardware filter times (typical)	
Inputs I1 to I8	
Signal change 0 -> 1	5 ms
Signal change 1 -> 0	5 ms
Permissible cable length to the sensor	30 m (to ensure conformance with EMC Directive 89/336/EEC)
Use of AC sensors	AC sensors in the voltage range < U _{IN} are limited in application (according to the input design)

Digital outputs

Number	4
Output design	Protected outputs according to EN 61131-2
Nominal output voltage	24 V DC
Nominal output current	500 mA

Diagnostic and status indicators

IEC 61131 runtime system (PLC)	FR, FF
Ethernet (ETH)	LINK, ACT
INTERBUS diagnostics (IL)	RDY, BSA, FAIL, PF

Diagnostic and status indicators	
Digital inputs and outputs	I1 to I8, E, Q1 to Q4
Supply voltages	US, UM, UL
PROFINET (ILC 170 ETH 2TX, ILC 190 ETH 2TX)	BF, SF

IEC 61131 runtime system	ILC 130 ETH	ILC 150 ETH	ILC 155 ETH, ILC 170 ETH 2TX	ILC 190 ETH 2TX
Programming system	PC Worx	PC Worx	PC Worx	PC Worx
Processing speed				
1 K mix instructions	1.7 ms	1.5 ms	1.5 ms	1.3 ms
1 K bit instructions	90 µs	90 µs	90 µs	90 µs
Shortest cycle time (for cyclic task)	1 ms	1 ms	1 ms	1 ms
Program memory	192 KB, 16 K instructions (IL)	256 KB, 21 K instructions (IL)	512 KB, 43 K instructions (IL)	1 MB, 86 K instructions (IL)
Data memory	192 KB	256 KB	512 KB	1 MB
Retentive data memory	8 KB, NVRAM	8 KB, NVRAM	48 KB, NVRAM	48 KB, NVRAM
Number of data blocks	Depends on data memory	Depends on data memory	Depends on data memory	Depends on data memory
Number of control tasks	8	8	8	8
Parameterization memory				
Integrated (ILC 130 ETH, ILC 150 ETH, ILC 155 ETH)	4 MB Flash memory (100,000 write access operations per sector, typical)	4 MB Flash memory (100,000 write access operations per sector, typical)	4 MB Flash memory (100,000 write access operations per sector, typical)	–
Plug-in, SD card (ILC 170 ETH 2TX, ILC 190 ETH 2TX)	–	–	256 MB (1,000,000 write access operations per sector, typical), see Section "Accessories" on page 5-8	256 MB (1,000,000 write access operations per sector, typical), see Section "Accessories" on page 5-8



Please note that the number of write access operations to the parameterization memory is limited. We recommend that you limit the number of write access operations on the parameterization memory in your application program by first storing data on the data memory and/or the memory for retentive data (NVRAM). Write access operations on the parameterization memory for small volumes of data (bit, byte) should not be possible in your application program. Data should only be transferred from the data memory/memory for retentive data to the parameterization memory if the data memory/memory for retentive data is full, i.e., data must be deleted first to enable further write access operations.

Real-time clock	
Accuracy	1 minute/week, maximum
Power reserve	3 days

Ambient conditions	
Degree of protection	IP20 (EN 60529:1991)
Permissible temperature (operation)	-25°C to +55°C
Permissible temperature (storage/transport)	-25°C to +85°C



This temperature range is only guaranteed if the Inline controller is mounted horizontally.

Permissible humidity (operation/storage/transport)	10% to 95% according to DIN EN 61131-2
Permissible air pressure (operation/storage/transport)	70 kPa to 106 kPa (up to 3000 m above sea level)

Mechanical tests

Vibration resistance according to EN 60068-2-6, IEC 60068-2-6	Operation: 5g
Shock test according to EN 60068-2-27, IEC 60068-2-27	25g

Conformance with EMC directive 2004/108/EC

Noise immunity test according to EN 61000-6-2

Electrostatic discharge (ESD)	EN 61000-4-2/ IEC 61000-4-2	Criterion B 6 kV contact discharge 8 kV air discharge
Electromagnetic fields	EN 61000-4-3 IEC 61000-4-3	Criterion A, Field strength 10 V/m
Fast transients (burst)	EN 61000-4-4/ IEC 61000-4-4	Criterion B Supply lines: 2 kV Signal/data lines: 2 kV
Surge test	EN 61000-4-5 IEC 61000-4-5	Criterion B Signal/data lines: 1 kV Supply lines: 0.5 kV
Conducted interference	EN 61000-4-6 IEC 61000-4-6	Criterion A Test voltage 10 V

Noise emission test according to EN 61000-6-4

Noise emission of housing	EN 55011	Class A
---------------------------	----------	---------

Approvals

For the latest approvals, please visit www.phoenixcontact.com or www.phoenixcontact.net/catalog.

5.2 Ordering data

5.2.1 Modules

Description	Type	Order No.	Pcs./Pkt.
Inline controller, including accessories (connectors and labeling fields)	ILC 130 ETH	2988803	1
Inline controller, including accessories (connectors and labeling fields)	ILC 150 ETH	2985330	1
Inline controller, including accessories (connectors and labeling fields)	ILC 155 ETH	2988188	1
Inline controller, including accessories (connectors and labeling fields)	ILC 170 ETH 2TX	2916532	1
Inline controller, including accessories (connectors and labeling fields)	ILC 190 ETH 2TX	2700527	1

5.2.2 Accessories

Description	Type	Order No.	Pcs./Pkt.
Inline connector set for Inline bus coupler with connected I/Os	IL BKDIO-PLSET	2878599	1
Connecting cable for connecting the Inline controller to a PC (V.24 (RS232) cable)	PRG CAB MINI DIN	2730611	1
256 MB SD memory card	SD FLASH 256MB	2988120	1
Program and configuration memory, plug-in, 256 Mbytes with license key for function block libraries, e.g., for: SNMP, SQL, wireless, motion functions, etc	SD FLASH 256MB APPLIC A	2988816	1
Program and configuration memory, plug-in, 2 GByte	SD FLASH 2GB	2988162	1
Program and configuration memory, plug-in, 2 Gbytes with license key for function block libraries, e.g., for: SNMP, SQL, wireless, motion functions, etc.	SD FLASH 2GB APPLIC A	2701190	1
QUINT POWER power supply units	See latest Phoenix Contact INTERFACE catalog		

5.2.3 Software

Description	Type	Order No.	Pcs./Pkt.
PC Worx Express automation software	PC WORX EXPRESS	2988670	1
PC Worx automation software	See latest Phoenix Contact AUTOMATION catalog		
Configuration and diagnostic software for Ethernet networks in the automation environment (Factory Manager)	FL SWT	2831044	1

5.2.4 Documentation

Description	Type	Order No.	Pcs./Pkt.
"Configuring and installing the INTERBUS Inline product range" user manual	IB IL SYS PRO UM E	2743048	1
"Automation terminals of the Inline product range" user manual	IL SYS INST UM E	2698737	1
Quick start guide, PCWorx Version 5.00 or later	UM QS EN PC WORX EXPRESS	–	1
Quick start guide, PC Worx Version 6.00 or later	UM QS EN PC WORX	–	1

Technical data and ordering data

Description	Type	Order No.	Pcs./Pkt.
"PROFINET basics" user manual	UM EN PROFINET SYS	-	1
"PROFINET IO controller/device functions" user manual	UM EN PROFINET CTRL DEV	-	1
"Applicative system redundancy" application note	AH EN APPLICATIVE SYSTEM REDUNDANCY	-	1

A Appendix: Service and maintenance

A 1 Error causes and remedies

Table A-1 Installation error causes and remedies

Error	Cause	Remedy
No outputs can be set.	The voltage supply U_S is absent (see diagnostic LED).	Connect the voltage supply.
The devices connected to the Inline controller cannot be read.	The voltage supply U_S is absent (see diagnostic LED).	Connect the voltage supply.
The IEC 61131 program is not running.	Mode selector switch in STP position.	Set mode selector switch to RUN/PROG position.
The serial interface is not operating.	The connector pin assignment of the programming cable or of the connector adapter used is incorrect.	Use the PRG CAB MINI DIN programming cable, Order. No. 2730611, for the Inline controller.
The devices on the remote bus cannot be started up.	The IBS IL 24 RB-T (-PAC) Inline terminal is not installed directly after the Inline controller.	Insert the terminal as the first Inline terminal directly next to the Inline controller.
The diagnostic LED of a device is flashing quickly.	The device has not been assembled correctly.	Check the connection to the previous module (bus contacts).
ILC 170 ETH 2TX/ILC 190 ETH 2TX The FR and FF LEDs of the are flashing.	The ILC 170 ETH 2TX/ ILC 190 ETH 2TX cannot be addressed/the parameterization memory (SD card) is not inserted.	Insert a valid parameterization memory (SD card) that has been approved by Phoenix Contact into the slot of the ILC 170 ETH 2TX/ILC 190 ETH 2TX (see Figure 2-11 on page 2-16).
The Inline controller cannot be addressed via the IP address.	The IP address on the Inline controller has been changed or does not match the IP settings of the network devices involved.	Check the IP settings and adapt them to your application, if necessary (see also Section "Assigning the IP address for the controller/ BootP server" on page 3-2).

A 2 Updating the Inline controller firmware

The firmware (integrated software on the Inline controller) can be updated using the Ethernet interface. Such firmware updates are used exclusively for the addition of new functions that are implemented within the scope of continuous product improvement. No firmware update is required for normal system operation.



To update the firmware, please proceed according to the "Firmware update ÷ 4.6F/1.13" application note. It can be downloaded at www.phoenixcontact.net/catalog.

A 3 Connecting unshielded cables

Unshielded cables are used to connect the I/O devices and the supply voltage to the Inline controller.

Connect these cables to the relevant Inline connectors using the spring-cage connection method. You may connect cables with diameters of 0.2 mm² to 1.5 mm² (24 - 16 AWG).




Figure A-1 Connecting unshielded cables

Wire the connectors according to your application.

When wiring, proceed as follows:

- Strip 8 mm off the cable.



Inline wiring is normally done without ferrules. However, it is possible to use ferrules. If using ferrules, make sure they are properly crimped.

- Push a screwdriver into the slot for the appropriate connection (Figure A-1, 1), so that you can plug the wire into the spring opening.
Phoenix Contact recommends the SFZ screwdriver 1 - 0.6x3.5 (Order No. 12 04 51 7).
- Insert the wire (Figure A-1, 2). Remove the screwdriver from the opening. This clamps the wire.

After installation, the wires and the terminal points should be labeled.

B Index

A

Applicative system redundancy 2-6

B

Basic wiring of an output 2-31

BootP 3-2, 3-3

BootP server 2-21

C

Communication path 2-21

Connecting the cables A-2

Connecting the supply voltage 2-27

Connecting unshielded cables A-2

Connection elements 2-9

Connector 2-19

Control cabinet 2-18

See also Terminal box

D

Diagnostic indicators 2-11

Digital inputs 2-30

DIN rail 2-18

E

Electronics base 2-19

End clamp 2-18

End plate 2-18

Error causes A-1

Error diagnostics 2-11

Ethernet 2-22

Ethernet interface 2-22

F

Fields of application

ILC 130 ETH 2-3

ILC 150 ETH, ILC 155 ETH, ILC 170 ETH 2TX, ILC 190 ETH 2TX 2-3

ILC 170 ETH 2TX, ILC 190 ETH 2TX 2-6

FTP functions 3-12

H

Hardware requirements 1-1

I

ILC 130 ETH, ILC 150 ETH, ILC 155 ETH

Connectors 2-9

Diagnostic and status indicators 2-9

Electronics base 2-9

End plate 2-9

Ethernet connection 2-9

Mode selector switch 2-9

Parameterization memory, integrated 2-15

Reset button 2-9

V.24 (RS-232) interface 2-9

ILC 170 ETH 2TX, ILC 190 ETH 2TX

Card holder 2-10

Connector 2-10

Diagnostic and status indicators 2-10

Electronics base 2-10

End plate 2-10

Ethernet connection 2-10

Mode selector switch 2-10

Parameterization memory, pluggable 2-15

Reset button 2-10

RS-232 interface 2-10

Slot for the parameterization memory 2-10

Inline local bus 2-3

INTERBUS 2-25

IP address

Setting the 3-2, 3-4

IP20 2-18

L

Local bus 2-25

M

MAC address 2-21

Mode selector switch 2-14

Mounting 2-18, 2-19

Mounting location 2-18

Mounting position 2-18

O

Operating elements 2-9

P

Parameterization memory	2-15
Parameterization memory, integrated	2-15
Parameterization memory, pluggable.....	2-15
Power supply	2-26
Power supply without fall-back characteristic curve	2-26,
5-1	

PROFINET

"Read PROFINET" dialog box	3-9
Integrating the IO device (example).....	3-8
IO device inserted	3-10
IO device process data.....	3-10
PROFINET IO device	3-5
Reading in PROFINET	3-8
Switching on the IO device function.....	3-5

R

Removal.....	2-18, 2-19
Replacement.....	2-21
Reset button.....	2-15
Resetting the Inline controller	2-15
Resetting the controller	3-6

S

Serial PRG interface.....	2-23
Sizing of the power supply	2-26
Software requirements	1-1
System variables.....	4-1

T

Terminal box	2-18
--------------------	------

U

Updating the firmware	A-1
-----------------------------	-----

V

V.24 (RS-232) cable.....	2-23
Voltage supply	
Connecting the	2-27