



ASSEMBLY INSTRUCTIONS:

- 1) Remove knockouts with a proper striking tool.
- 2) Line up holes on Anti-tip bracket with holes on cabinet.
- 3) Insert 1/4-20 screw through each hole and fasten securely as shown with 1/4-20 nut.

PARTS LIST		
ITEM No.	DESCRIPTION	QTY
1	RCSC CABINET (SOLD SEPARATELY)	1
2	RCSC ANTI-TIP BRACKET	1
3	1/4-20 SCREW	2
4	1/4-20 NUT	2

TOOL BOX



Phillips
Screw Driver

